

## How to connect the Texas Instruments MSP430F5172 Development SchmartModule to the Launchpad for full debugger use if you don't have a FET430 tool.

1. Remove jumpers from J3 of the Launchpad;  
(Note that all connections on the LaunchPad are on the "EMULATION" side of the header.)
2. Connect GND from LaunchPad J3 to '5172 board, JP1-9
3. Connect TEST from LaunchPad J3 to '5172 board, JP1-7
4. Connect RST from LaunchPad J3 to '5172 board, JP1-1
5. Connect VCC from Launchpad J3 to '5172 board, J5-2

